# E-Riser

Make your next Special Event SPECTACULAR with the E-Riser. Bring new dimensions into your floral arrangements and event lighting with the

new 28" high rechargeable LED lighted E-Riser.

Perfect for adding exquisite coloured lighting detail
to a wedding or party table arrangement.

This clear, bubble-filled riser, outputs Bright White light,
10 other colours, or cycles the RGB spectrum.

You set the column colour to your need. the column will iluminate in a white glow or in a choice of different solid colours (red, blue, green, pink, teal, and purple). You can mix the white into the the solid colours for a more pastel effect. You can also choose the rotating RGB colour feature to bring a kinetic action into your display or event. 8 hours of continous operation assures that this appliance will function for the entire length of any event. The secure attachment of the column to the base and to the top pan and the weight of the base makes this assembly very stable and sturdy for a impressive amount of loading and assures your designs need not be limited.

# RED GREEN BLUE PURPLE TEAL

## Column lighting selections:

White light

Different solid colors

Red, Blue, Green, Pink, Teal, Purple rotating RGB colors

### Output:

20 bright LEDs

# AC adapter:

battery recharging 6v 300mA

# **Battery Life:**

8 hours per charge allow 15 hours for initial charge, 10 hours there after, mercury free

### Power:

rechargeable batteries

Height: 26" (66cm)

Item Code: E-Riser A22800



- 1 Press to turn on continuous white light. Turn off white before making a color selection or leave it on for a pastel effect.
- 2 Repeatedly press to turn on alternate solid colors. The final press will turn on the rotating RGB colors.
- 3 To turn the E-Riser ON and OFF move the white switch right or left
- 4 To charge the battery insert the male end of the AC adapter into the charging port then plug the adaptor into an outlet. The first charge will take 15 hours and 10 hours there after.

The E-Riser can also operate continuously with the AC adaptor.

5 The charging indicator light is red when charging and turns green when batteries are fully charged.

